

LOCOSYS Technology Inc.

Product name	Description	Version
LS20030U	GPS smart antenna module/USB,9600BPS,30x30mm	
LS20031U	GPS smart antenna module/TTL,9600BPS,30x30mm	1.0
LS20032U	GPS smart antenna module/RS232,9600BPS,30x30mm	

# Datasheet of GPS smart antenna module, LS2003xU series



### 1 Introduction

LS2003xU series products are complete GPS smart antenna receivers, including an embedded antenna and GPS receiver circuits, designed for a broad spectrum of OEM system applications. The product is based on the proven technology found in LOCOSYS 66 channel GPS SMD type receiver MC-1612 that uses MediaTek chip solution. The GPS smart antenna will acquire up to 66 satellites at a time while providing fast time-to-first-fix, one-second navigation update and low power consumption. It can provide you with superior sensitivity and performance even in urban canyon and dense foliage environment. Its far-reaching capability meets the sensitivity requirements of car navigation as well as other location-based applications.

This module supports hybrid ephemeris prediction to achieve faster cold start. One is self-generated ephemeris prediction that is no need of both network assistance and host CPU's intervention. This is valid for up to 3 days and updates automatically from time to time when GPS module is powered on and satellites are available. The other is server-generated ephemeris prediction that gets from an internet server. This is valid for up to 14 days. Both ephemeris predictions are stored in the on-board flash memory and perform a cold start time less than 15 seconds.

### 2 Features

- MediaTek high sensitivity solution
- Support 66-channel GPS
- Low power consumption
- Fast TTFF at low signal level
- Built-in 12 multi-tone active interference canceller
- Free hybrid ephemeris prediction to achieve faster cold start
- Built-in data logger
- Up to 10 Hz update rate
- Capable of SBAS (WAAS, EGNOS, MSAS, GAGAN)



#### LOCOSYS Technology Inc. 20F.-13, No.79, Sec. 1, Xintai 5th Rd., Xizhi District, New Taipei City 221, Taiwan 886-2-8698-3698 886-2-8698-3699 www.locosystech.com

- Support Japan QZSS
- Indoor and outdoor multi-path detection and compensation
- Support  $\pm 11$ ns high accuracy time pulse (PPS)
- Build-in micro battery to reserve system data for rapid satellite acquisition
- LED indicator for GPS fix or not fix

## 3 Application

- Personal positioning and navigation
- Automotive navigation
- Marine navigation




Fig 3-1 System block diagram of LS20030U




Fig 3-2 System block diagram of LS20031U



# 




Fig 3-3 System block diagram of LS20032U



### 4 GPS receiver

Chip	MediaTek MT3339		
Frequency	L1 1575.42MHz, C/A code		
Channels	Support 66 channels (22 Trac	cking, 66 Acquisition)	
Update rate	1Hz default, up to 10Hz		
	Hot start (Open Sky)	< 1s (typical)	
Acquisition Time	Cold Start (Open Sky)	32s (typical) without AGPS	
		<15s (typical) with AGPS (hybrid ephemeris prediction)	
Position Accuracy	Autonomous	2.5m (CEP)	
	SBAS	2.5m (depends on accuracy of correction data)	
Datum	WGS-84 (default)		
Max. Altitude	< 50,000 m		
Max. Velocity	< 515 m/s		
		9600 bps <sup>(1)</sup> , 8 data bits, no parity, 1 stop bits (default)	
Protocol Support	NMEA 0183 ver 3.01	1Hz: GGA, GLL, GSA, GSV, RMC, VTG	

Note 1: Both baud rate and output message rate are configurable to be factory default.

# 5 Software interface

### 5.1 NMEA output message

Table 5.1-1 NMEA output message

NMEA record	Description	
GGA	Global positioning system fixed data	
GLL	Geographic position - latitude/longitude	
GSA	GNSS DOP and active satellites	
GSV	NSS satellites in view	
RMC	Recommended minimum specific GNSS data	
VTG	Course over ground and ground speed	

# • GGA--- Global Positioning System Fixed Data

Table 5.1-2 contains the values for the following example:

\$GPGGA, 053740.000, 2503.6319, N, 12136.0099, E, 1, 08, 1.1, 63.8, M, 15.2, M, 0000\*64

Table5.1-2 GGA Data Format

Name	Example	Units	Description
Message ID	\$GPGGA		GGA protocol header
UTC Time	053740.000		hhmmss.sss
Latitude	2503.6319		ddmm.mmm



LOCOSYS Technology Inc. 20F.-13, No.79, Sec. 1, Xintai 5th Rd., Xizhi District, New Taipei City 221, Taiwan 🕾 886-2-8698-3698 🖃 886-2-8698-3699 Owww.locosystech.com

N/S indicator	N		N=north or S=south
Longitude	12136.0099		dddmm.mmmm
E/W Indicator	Е		E=east or W=west
Position Fix Indicator	1		See Table 5.1-3
Satellites Used	08		Range 0 to 12
HDOP	1.1		Horizontal Dilution of Precision
MSL Altitude	63.8	mters	
Units	М	mters	
Geoid Separation	15.2	mters	
Units	М	mters	
Age of Diff. Corr.		second	Null fields when DGPS is not used
Diff. Ref. Station ID	0000		
Checksum	*64		
<cr> <lf></lf></cr>			End of message termination

Table 5.1-3 Position Fix Indicators

Value	Description
0	Fix not available or invalid
1	GPS SPS Mode, fix valid
2	Differential GPS, SPS Mode, fix valid
3-5	Not supported
6	Dead Reckoning Mode, fix valid

### • GLL--- Geographic Position – Latitude/Longitude

Table 5.1-4 contains the values for the following example:

\$GPGLL,2503.6319,N,12136.0099,E,053740.000,A,A\*52

Table 5.1-4 GLL Data Format

Name	Example	Units	Description
Message ID	\$GPGLL		GLL protocol header
Latitude	2503.6319		ddmm.mmmm
N/S indicator	N		N=north or S=south
Longitude	12136.0099		dddmm.mmmm
E/W indicator	Е		E=east or W=west
UTC Time	053740.000		hhmmss.sss
Status	А		A=data valid or V=data not valid
			A=autonomous, D=DGPS, E=DR, N=Data not valid,
Mode	А		R=Coarse Position, S=Simulator



#### LOCOSYS Technology Inc.

Checksum	*52	
<cr> <lf></lf></cr>		End of message termination

#### • GSA----GNSS DOP and Active Satellites

Table 5.1-5 contains the values for the following example:

\$GPGSA,A,3,24,07,17,11,28,08,20,04,,,,,2.0,1.1,1.7\*35

Table 5.1-5 GSA Data Format

Name	Example	Units	Description
Message ID	\$GPGSA		GSA protocol header
Mode 1	А		See Table 5.1-6
Mode 2	3		See Table 5.1-7
ID of satellite used	24		Sv on Channel 1
ID of satellite used	07		Sv on Channel 2
ID of satellite used			Sv on Channel 12
PDOP	2.0		Position Dilution of Precision
HDOP	1.1		Horizontal Dilution of Precision
VDOP	1.7		Vertical Dilution of Precision
Checksum	*35		
<cr> <lf></lf></cr>			End of message termination

Table 5.1-6 Mode 1

Value	Description	
М	Manual- forced to operate in 2D or 3D mode	
А	Automatic-allowed to automatically switch 2D/3D	

Table 5.1-7 Mode 2

Value	Description
1	Fix not available
2	2D
3	3D

### • GSV----GNSS Satellites in View

Table 5.1-8 contains the values for the following example:

\$GPGSV, 3, 1, 12, 28, 81, 285, 42, 24, 67, 302, 46, 31, 54, 354, ,20, 51, 077, 46\*73

 $\label{eq:GPGSV} \$GPGSV, 3, 2, 12, 17, 41, 328, 45, 07, 32, 315, 45, 04, 31, 250, 40, 11, 25, 046, 41*75$ 

\$GPGSV, 3, 3, 12, 08, 22, 214, 38, 27, 08, 190, 16, 19, 05, 092, 33, 23, 04, 127, \*7B

Table 5.1-8 GSV Data Format

Name Exam	ple Units	Description
-----------	-----------	-------------



LOCOSYS Technology Inc. 20F.-13, No.79, Sec. 1, Xintai 5th Rd., Xizhi District, New Taipei City 221, Taiwan 🕾 886-2-8698-3698 🖃 886-2-8698-3699 Owww.locosystech.com

Message ID	\$GPGSV		GSV protocol header
Total number of messages <sup>1</sup>	3		Range 1 to 4
Message number <sup>1</sup>	1		Range 1 to 4
Satellites in view	12		
Satellite ID	28		Channel 1 (Range 01 to 196)
Elevation	81	degrees	Channel 1 (Range 00 to 90)
Azimuth	285	degrees	Channel 1 (Range 000 to 359)
SNR (C/No)	42	dB-Hz	Channel 1 (Range 00 to 99, null when not tracking)
Satellite ID	20		Channel 4 (Range 01 to 32)
Elevation	51	degrees	Channel 4 (Range 00 to 90)
Azimuth	077	degrees	Channel 4 (Range 000 to 359)
SNR (C/No)	46	dB-Hz	Channel 4 (Range 00 to 99, null when not tracking)
Checksum	*73		
<cr> <lf></lf></cr>			End of message termination

1. Depending on the number of satellites tracked multiple messages of GSV data may be required.

### • RMC---Recommended Minimum Specific GNSS Data

Table 5.1-9 contains the values for the following example:

\$GPRMC,053740.000,A,2503.6319,N,12136.0099,E,2.69,79.65,100106,,,A\*53

Name	Example	Units	Description
Message ID	\$GPRMC		RMC protocol header
UTC Time	053740.000		hhmmss.sss
Status	А		A=data valid or V=data not valid
Latitude	2503.6319		ddmm.mmmm
N/S Indicator	N		N=north or S=south
Longitude	12136.0099		dddmm.mmmm
E/W Indicator	Е		E=east or W=west
Speed over ground	2.69	knots	Тгие
Course over ground	79.65	degrees	
Date	100106		ddmmyy
Magnetic variation		degrees	
Variation sense			E=east or W=west (Not shown)
			A=autonomous, D=DGPS, E=DR, N=Data not valid,
Mode	A		R=Coarse Position, S=Simulator
Checksum	*53		
<cr> <lf></lf></cr>			End of message termination



### • VTG---Course Over Ground and Ground Speed

Table 5.1-10 contains the values for the following example:

\$GPVTG,79.65,T,,M,2.69,N,5.0,K,A\*38

*Table 5.1-10* VTG Data Format

Name	Example	Units	Description			
Message ID	\$GPVTG		VTG protocol header			
Course over ground	79.65	degrees	Measured heading			
Reference	Т		True			
Course over ground		degrees	Measured heading			
Reference	М		Magnetic			
Speed over ground	2.69	knots	Measured speed			
Units	Ν		Knots			
Speed over ground	5.0	km/hr	Measured speed			
Units	K		Kilometer per hour			
Mode	А		A=autonomous, D=DGPS, E=DR, N=Data not valid, R=Coarse Position, S=Simulator			
Checksum	*38					
<cr> <lf></lf></cr>			End of message termination			

### 5.2 Proprietary NMEA input message

Please refer to MTK proprietary message.

### 5.3 Examples to configure the power mode of GPS module


The GPS module supports different power modes that user can configure by issuing software commands.

### 5.3.1 Standby mode

User can issue software command to make GPS module go into standby mode that consumes less than 200uA current. GPS module will be awaked when receiving any byte. The following flow chart is an example to make GPS module go into standby mode and then wake up.




#### LOCOSYS Technology Inc. 20F.-13, No.79, Sec. 1, Xintai 5th Rd., Xizhi District, New Taipei City 221, Taiwan 886-2-8698-3698 886-2-8698-3699 www.locosystech.com



# 5.3.2 Periodic mode


When GPS module is commanded to periodic mode, it will be in operation and standby periodically. Its status of power consumption is as below chart.



The following flow chart is an example to make GPS module go into periodic mode



and then back to normal operation mode.




# 5.3.3 AlwaysLocate<sup>TM</sup> mode

AlwaysLocate<sup>TM</sup> is an intelligent controller of periodic mode. Depending on the environment and motion conditions, GPS module can adaptively adjust working/standby time to achieve balance of positioning accuracy and power consumption. In this mode, the host CPU does not need to control GPS module until the host CPU needs the GPS position data. The following flow chart is an example to make GPS module go into AlwaysLocate<sup>Tm</sup> mode and then back to normal operation mode.

Note: AlwaysLocate<sup>TM</sup> is a trade mark of MTK.





### 5.4 Data logger

The GPS module has internal flash memory for logging GPS data. The configurations include time interval, distance, speed, logging mode, and ... etc. For more information, please



contact us.

### 5.5 Examples to configure the update rate of GPS module

The GPS module supports up to 10Hz update rate that user can configure by issuing software commands. Note that the configurations by software commands are stored in the battery-backed SRAM that is powered through VBACKUP pin. Once it drains out, the default/factory settings will be applied.

Due to the transmitting capacity per second of the current baud rate, GPS module has to be changed to higher baud rate for high update rate of position fix. The user can use the following software commands to change baud rate.

Baud rate	Software command
Factory default	\$PMTK251,0*28 <cr><lf></lf></cr>
4800	\$PMTK251,4800*14 <cr><lf></lf></cr>
9600	\$PMTK251,9600*17 <cr><lf></lf></cr>
19200	\$PMTK251,19200*22 <cr><lf></lf></cr>
38400	\$PMTK251,38400*27 <cr><lf></lf></cr>
57600	\$PMTK251,57600*2C <cr><lf></lf></cr>
115200	\$PMTK251,115200*1F <cr><lf></lf></cr>

Note: <CR> means Carriage Return, i.e. 0x0D in hexadecimal. <LF> means Line Feed, i.e. 0x0A in hexadecimal.

If the user does not want to change baud rate, you can reduce the output NMEA sentences by the following software commands.

NMEA sentence	Software command			
Factory default	\$PMTK314,-1*04 <cr><lf></lf></cr>			
Only GLL at 1Hz	\$PMTK314,1,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0			
Only RMC at 1Hz	\$PMTK314,0,1,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0			
Only VTG at 1Hz	\$PMTK314,0,0,1,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0			
Only GGA at 1Hz	\$PMTK314,0,0,0,1,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0			
Only GSA at 1Hz	\$PMTK314,0,0,0,0,1,0,0,0,0,0,0,0,0,0,0,0,0,0,0			
Only GSV at 1Hz	\$PMTK314,0,0,0,0,0,1,0,0,0,0,0,0,0,0,0,0,0,0,0			
Only ZDA at 1Hz	\$PMTK314,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0,0			
RMC, GGA, GSA				
at 1Hz and GSV at	\$PMTK314,0,1,0,1,1,5,0,0,0,0,0,0,0,0,0,0,0,0,0,0			
0.2Hz				
If the command is correct and executed, GPS module will output message				
\$PMTK001,314,3*36 <cr><lf></lf></cr>				



confi	onfigure it to high update rate of position fix by the following commands.						
	Interval of position fix	Software command					
	Every 100ms (10Hz) <sup>(1)</sup>	\$PMTK220,100*2F <cr><lf></lf></cr>					
	Every 200ms (5Hz)	\$PMTK220,200*2C <cr><lf></lf></cr>					
	Every 500ms (2Hz)	\$PMTK220,500*2B <cr><lf></lf></cr>					
	Every 1000ms (1Hz)	\$PMTK220,1000*1F <cr><lf></lf></cr>					
	Every 2000ms (0.5Hz) <sup>(2)</sup>	\$PMTK220,2000*1C <cr><lf></lf></cr>					

After the GPS module is changed to higher baud rate or reduced NMEA sentence, the user can configure it to high update rate of position fix by the following commands.

Note 1: The minimum interval of position fix is 100ms, i.e. the maximum update rate is 10Hz.

Note 2: The current consumption is the same with the update rate of 1Hz.

If the command is correct and executed, GPS module will

output message \$PMTK001,220,3\*30<CR><LF>

### 6 LED indicator

The red LED is an indicator of GPS positioning status. In continuous power mode, it flashes once per second when position is fixed. Otherwise, it is off. The timing in detail is as below.





Fig 6.1 LED indicator of GPS positioning status



7 Pin assignment and descriptions



# • LS20030U

Pin #	Name	Туре	Description			
1	VBUS	Р	B power input			
2	D-		D- line			
3	D+		D+ line			
4	GND	Р	Ground			
5	TIMEPULSE	0	PPS, default 100ms pulse/sec when 3D fix is available.			
6	NC		Not connect			

# • LS20031U

Pin #	Name	Туре	Description
1	VCC	Р	Power input
2	RX	Ι	Data input (TTL level)
3	ТХ	0	Data output (TTL level)
4	GND	Р	Ground
5	TIMEPULSE	0	PPS, default 100ms pulse/sec when 3D fix is available.
6	NC		Not connect

# • LS20032U

Pin #	Name	Туре	Description
1	VCC	Р	Power input
2	RX	Ι	Data input (RS232 level)
3	TX	0	Data output (RS232 level)
4	GND	Р	Ground
5	TIMEPULSE	0	PPS, default 100ms pulse/sec when 3D fix is available.
6	NC		Not connect

LOCOSYS

# 8 DC & Temperature characteristics

# 8.1 DC Electrical characteristics

Parameter	Symbol	Product	Min.	Тур.	Max.	Units
		LS20030U	4.75	5	5.25	
Input voltage	VCC	LS20031U	3	3.3	3.6	V
		LS20032U	4.5	5	5.5	
		LS20030U		43 (1)		
Input current	Icc	LS20031U		26 <sup>(1)</sup>		mA
		LS20032U		31 (1)		
High Level Input Voltage	VIH		2.0		3.6	V
Low Level Input Voltage	VIL		0		0.8	V
High Level Output Voltage	Vон		2.4		3.3	V
Low Level Output Voltage	Vol	- LS20031U			0.4	V
High Level Output Current	Іон			2		mA
Low Level Output Current	Iol			2		mA

1. Measured when position fix (1Hz) is available and the function of self-generated ephemeris prediction is inactive.

# 8.2 Temperature characteristics

Parameter	Symbol	Min.	Тур.	Max.	Units
Operating Temperature	Topr <sup>(1)</sup>	-40	-	85	°C
Storage Temperature	Tstg <sup>(2)</sup>	-40	25	85	°C


Note

1. battery:  $-20 \sim 60^{\circ}$ C

2. battery:  $-40 \sim 60^{\circ}$ C

LOCOSYS

# 9 Mechanical specification






# 10 Product handling

# 10.1 ESD precaution

GNSS modules are electrostatic sensitive devices. Handling the modules without proper ESD protection may result in severe damage to them. ESD protection must be implemented throughout the processing, handling and even when the modules are being returned for repair.

# 10.2 Packaging





## 10.3 Storage

We recommend storing the smart antenna module in a dry place, such as moisture-proof cabinet. The shelf life of the module package is about 6 months from the packaging date when it is stored in a non-condensing storage environment ( $<30^{\circ}C/60\%$  RH).

# 11 Ordering information

Product name	Description	Remark
LS20030U	GPS smart antenna, USB	
LS20031U	GPS smart antenna, TTL	GPS/QZSS: L1 C/A
LS20032U	GPS smart antenna, RS232	



# Document change list

# Revision 1.0

• First release on May 6, 2022.